

# HAM Radio avec le Raspberry Pi Partie 10



Sommaire :

# Partie 10 : Serveur de streaming avec Rtl sdr.





Prérequis : Partie 4 : Utilisation du système d'exploitation Raspbian Lite.

10.1 Présentation de l'ensemble serveur / client	P. 2
10.2 Installation des drivers rtl-sdr	P. 2
10.3 Serveur rtl_tcp avec 4 logiciels SDR	P. 7
10.3.1 Sdrsharp 10.3.2 Sdr console 10.3.3 Hdsdr 10.3.4 Sdruno	P. 7 P. 10 P. 12 P. 14
10.4 Installation du serveur SPY Server	P. 17
10.5 Test avec 2 logiciels clients	P. 19
10.5.1 Sdrsharp 10.5.2 Sdr console	P. 19 P. 20
10.6 Configuration de la box ADSL	P. 21
10.7 Conclusion Version du 31/10/2020 V1.0 sur RPI3	P 21

#### F4GOH – KF4GOH

# **10.1 Présentation de l'ensemble serveur / client**

Dans ce tutoriel, il s'agit de mettre en œuvre un Raspberry Pi en tant que serveur pour faire de l'écoute à distance sur un PC. A la différence du tutoriel 6 sur OpenWebRX, le client (PC) utilise un des 4 logiciels (Hdsdr, Sdrsharp, Sdr console, Sdruno). L'avantage est que l'écoute sera beaucoup plus fluide qu'avec OpenWebRX, tout en disposant de toutes les fonctionnalités des logiciels de réception SDR. La communication entre le client et le serveur se fera en TCP/IP.



Bien évidemment il est possible d'avoir une connexion entre le serveur et le client via Internet. Dans ce cas il faudra configurer la BOX ADSL comme décrit dans le tutoriel 6.8 : Accéder au web SDR depuis l'extérieur du QRA.



## 10.2 Installation des drivers rtl-sdr

Cette fois ci, j'ai utilisé les deux liens suivants afin d'installer des pilotes pour la clé RTL-SDR V3. Cette version dispose d'améliorations par rapport au pilote décrit dans le tutoriel 3.

https://www.rtl-sdr.com/rtl-sdr-blog-v-3-dongles-user-guide/

https://github.com/rtlsdrblog/rtl-sdr-blog

Utiliser Raspbian Lite sans interface graphique. Penser à exécuter ces commandes si cela n'est pas déjà fait.

# sudo apt update sudo apt upgrade sudo apt install git

Récupérer les fichiers :

git clone git://github.com/rtlsdrblog/rtl-sdr-blog.git



Installer les bibliothèques.

```
sudo apt install build-essential cmake usbutils libusb-1.0-0-dev
```

```
pi@raspberrypi:~/rtl-sdr/build $ sudo apt install build-essential cmake usbutils
 libusb-1.0-0-dev
Lecture des listes de paquets... Fait
Construction de l'arbre des dépendances
Lecture des informations d'état... Fait
build-essential est déjà la version la plus récente (12.6).
usbutils est déjà la version la plus récente (1:010-3).
Les paquets suivants ont été installés automatiquement et ne sont plus nécessair
es :
  libmicrodns0 libqt5charts5 xlog-data
Veuillez utiliser « sudo apt autoremove » pour les supprimer.
Les paquets supplémentaires suivants seront installés :
 cmake-data libjsoncpp1 librhash0 libusb-1.0-doc libuv1
Paquets suggérés :
  cmake-doc ninja-build
Les NOUVEAUX paquets suivants seront installés :
  cmake cmake-data libjsoncpp1 librhash0 libusb-1.0-0-dev libusb-1.0-doc
  libuv1
0 mis à jour, 7 nouvellement installés, 0 à enlever et 0 non mis à jour.
Il est nécessaire de prendre 40578 ko dans les archives.
Après cette opération, 23,6 Mo d'espace disque supplémentaires seront utilisés.
Souhaitez-vous continuer ? [O/n]
```

Taper ces commandes dans l'ordre :



Found libusb-1.0, version 1.0.22

#### sudo make install

pi@raspberrypi:~/rtl-sdr-blog/build \$ sudo make install Scanning dependencies of target rtlsdr\_shared 3%] Building C object src/CMakeFiles/rtlsdr\_shared.dir/librtlsdr.c.o 6%] Building C object src/CMakeFiles/rtlsdr\_shared.dir/tuner\_e4k.c.o 9%] Building C object src/CMakeFiles/rtlsdr\_shared.dir/tuner\_fc0012.c.o 12%] Building C object src/CMakeFiles/rtlsdr\_shared.dir/tuner 15%] Building C object src/CMakeFiles/rtlsdr shared.dir/tuner 18%] Building C object src/CMakeFiles/rtlsdr shared.dir/tuner 21%] Linking C shared library librtlsdr.so [ 21%] Built target rtlsdr\_shared Scanning dependencies of target convenience\_static [ 25%] Building C object src/CMakeFiles/convenience static.dir/convenience/conve [ 28%] Linking C static library libconvenience static.a 28%] Built target convenience static

sudo cp ../rtl-sdr.rules /etc/udev/rules.d/ sudo ldconfig



# sudo nano /etc/modprobe.d/rtlsdr-blacklist.conf

pi@raspberrypi:~/rtl-sdr-blog/build \$ sudo nano /etc/modprobe.d/rtlsdr-blacklist.conf

```
blacklist dvb usb rtl28xxu
blacklist rt12832
blacklist rtl2830
blacklist dvb usb rtl2832u
blacklist dvb usb v2
blacklist dvb core
```

Copier-coller la liste ci-dessus dans l'éditeur nano. Rappel clic droit : pour coller le texte dans l'éditeur nano.





Redémarrer le Raspberry PI : pi@raspberrypi:~/rtl-sdr-blog/build \$ sudo reboot

sudo reboot

Vérification : Brancher la clé rtl-sdr sur un port USB de la Raspberry Pi. Connecter la clé rtl-sdr à la Raspberry Pi sur un port USB de libre.



Vérifier la présence de la clé rtl-sdr. Avec LXTerminal ou Putty, taper la ligne de commande suivante :

lsusb

Localiser la clé rtl-sdr : RTL238 DVB-T

Cas de la Raspberry Pi 3 :

```
pi@raspberrypi:~
                 $ lsusb
Bus 001 Device 004: ID Obda:2838 Realtek Semiconductor Corp. RTL2838 DVB-T
Bus 001 Device 003: ID 0424:ec00 Standard Microsystems Corp. SMSC9512/9514 Fast
Ethernet Adapter
Bus 001 Device 002: ID 0424:9514 Standard Microsystems Corp. SMC9514 Hub
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
```

#### Cas de la Raspberry Pi 4 :

pi@raspberrypi:~ \$ lsusb Bus 002 Device 001: ID 1d6b:0003 Linux Foundation 3.0 root hub Bus 001 Device 003: ID 0bda:2838 Realtek Semiconductor Corp. RTL2838 DVB-T Bus 001 Device 002: ID 2109:3431 VIA Labs, Inc. Hub Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub

Avec LXTerminal ou Putty, taper la ligne de commande suivante : (attention tiret du bas)

La clé rtl-sdr devrait être reconnue, si ce n'est pas le cas, débrancher et rebrancher la clé et recommencer le test.

pi@raspberrypi:~ \$ rtl_test
Found 1 device(s):
0: Realtek, RTL2838UHIDIR, SN: 00000001
Using device 0: Generic RTL2832U OEM
Found Rafael Micro R820T tuner
Supported gain values (29): 0.0 0.9 1.4 2.7 3.7 7.7 8.7 12.5 14.4 15.7 16.6 19.7
20.7 22.9 25.4 28.0 29.7 32.8 33.8 36.4 37.2 38.6 40.2 42.1 43.4 43.9 44.5 48.0
49.6
[R82XX] PLL not locked!
Sampling at 2048000 S/s.
Info: This tool will continuously read from the device, and report if
samples get lost. If you observe no further output, everything is fine.
Reading samples in async mode
^CSignal caught, exiting! Ctrl+C
User cancel, exiting
Samples per million lost (minimum): 0
pi@raspberrypi:~ \$ ^C

Quitter le programme en appuyant simultanément sur les touches Ctrl et la touche c (Ctrl+c)

rtl test

## 10.3 Serveur rtl\_tcp avec 4 logiciels SDR

#### 10.3.1 Sdrsharp

Installer le logiciel Sdrsharp décrit dans le tutoriel 9.2.3, page 7. Cette fois ci la clé de réception RTL\_SDR est branchée sur le Raspberry pi. Le but est d'y accéder via le réseau local. L'utilisation s'effectue en deux étapes :

- Exécution du serveur rtl\_tcp sur le Raspberry PI ;
- Connexion sur le Raspberry PI avec le logiciel Sdrsharp.

Identifier l'adresse IP de la Raspberry PI :

#### ifconfig

```
pi@raspberrypi:~ $ ifconfig
eth0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
    inet 192.168.1.55    netmask 255.255.255.0    broadcast 192.168.1.255
    inet6 fe80::8a7a:b574:ec19:dbce    prefixlen 64    scopeid 0x20<link>
    ether b8:27:eb:52:7f:d4    txqueuelen 1000 (Ethernet)
    RX packets 1055    bytes 146517 (143.0 KiB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 238    bytes 32568 (31.8 KiB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

L'adresse IP de ma RPI est : 192.168.1.55

Cette commande avec une option « factice » permet d'obtenir toutes les configurations possibles du serveur en lien avec la clé Rtl-sdr.

rtl\_tcp -h

```
pi@raspberrypi:~ $ rtl_tcp -h
rtl_tcp: invalid option -- 'h'
rtl_tcp, an I/Q spectrum server for RTL2832 based DVB-T receivers
Usage: [-a listen address]
    [-p listen port (default: 1234)]
    [-f frequency to tune to [Hz]]
    [-g gain (default: 0 for auto)]
    [-s samplerate in Hz (default: 2048000 Hz)]
    [-b number of buffers (default: 15, set by library)]
    [-n max number of linked list buffers to keep (default: 500)]
    [-d device index (default: 0)]
    [-P ppm_error (default: 0)]
    [-T enable bias-T on GPIO PIN 0 (works for rtl-sdr.com v3 dongles)]
    [-D enable direct sampling (default: off)]
```

#### F4GOH – KF4GOH Ecoute en VHF et UHF

Exécuter la commande suivante en veillant bien à remplacer l'adresse IP de la Raspberry Pi par la vôtre.

rtl tcp -a 192.168.1.55



Exécuter le logiciel Sdrsharp et exécuter les 4 étapes suivantes dans l'ordre.



Arrêter l'écoute sur Sdrsharp = . Puis stopper le serveur avec les touches CTRL+C.



Exécuter la commande suivante sur le serveur RPI (mode conversion directe) en veillant bien à remplacer l'adresse IP de la Raspberry Pi par la vôtre.



# rtl tcp -a 192.168.1.55 -D



## F4GOH – KF4GOH

## 10.3.2 Sdr console

Installer le logiciel Sdr console décrit dans le tutoriel 9.2.4, page 9.

Exécuter Sdr console <sup>(Console</sup>, puis choisir RTL Dongle TCP



RTL SDR Definition	ns			
Model Serial A	Address Port	Gains	F	
Add	<b>4</b> Edit	Delete	h	
RTL SDR Dor	RTL SDR De	finition		
rtl_tcp prog	Address:	192.168.1.55 5	Ad	d Definitions
• The	Port:	1234 Default is 1234		1 device found
• Ase • The	Model:	RTL Dongle (TCP)		You have no definitions for RTL Dongle TCP.
• The	Serial:	001		Select 'Add' to add this definition to the list.
The RF gains	Gains:	49.6,48.0,44.5,43.9,43.4,42.1,40.2,38.6,37.2,36.4,33.8,32.8,29.7,28.0,25.4,		
are loaded k	Tuner:	R820T E4000 FC0012 FC0013 FC2580 None None	•	10 Add Add this definition to the list
VOU are ur	8	7		
ОК	ОК	Cancel		Annuler



F4GOH ·	– KF4	IGOH									Tutorie
Select R	adio	-				23	Radio	Definitions			×
All	Local	⇔ Server					Q Sea	arch 👻 🛛 Add	Edit Delete		Text viewer
Name		Model	Frequency	Serial	Address	Option	Enable	Name	Model	Frequency	Serial
RTL Dongle	e (TCP)	RTL Dongle (TCP)	0 - 30 MHz	001	192. 168. 1.55:: 1234	+Gains=-	1	PlutoSDR RTL Dongle (TCP) RTL Dongle USB - R820T	PlutoSDR RTL Dongle (TCP) RTL Dongle USB - R820T	0 - 3800 MHz 0 - 30 MHz 50 - 2000 MHz	104473dc59 001 00000001
Bandwidth: Sta 25 IF Display	2.048 art	14 15	0s	96.4	Defin 00 s	itions	Show t Cc In 12	hese options onverter selection Edit vert spectrum ave Cancel	Autostart option Online help	<u>5</u>	
Mode			•		95.000	96.000					

Exécuter la commande suivante sur le serveur RPI en veillant bien à remplacer l'adresse IP de la Raspberry Pi par la vôtre.

# rtl\_tcp -a 192.168.1.55

Cliquer sur Start pour démarrer l'écoute. La démarche est identique pour une écoute en HF avec l'option **-D** 

	-	1		📀 🖕 🖻 🔊 :	;		RT	L Dongle (TCP)	:: SDR Con	sole v3.0.25				X
	П	ome	View	/ Receive	Transmit	Rec/Playback	Favourites	Memories	Tools	Help			🛞 Style	- 🔅
Sel Ra	ect s	€ Start	Stop	中小 Bandwidth 小 Calibration 融 Frequency	RF Gair	Radio Configuration	Previous His	tory Always On Top	Child Instance	Lock Screer	Auto-m Ena Shot	able Dations Options		
				Radio			RX Frequer	ncy	Exti	ras		Wideband DSP		
Rece RX 1	ive 10	<b>0</b> 5	.4	40 99.50	<ul> <li>-20 de</li> <li>-30 de</li> <li>-40 de</li> <li>-50 de</li> </ul>	3m -140 -140 -120 -120 -120 -120 -120 -120 -120 -12	-100 -80 -60	40 -20 °				2	-20 dBm -30 dBm -40 dBm -50 dBm	Auto -15 -30
На	ut-parleu	irs (Rea	litek Higi	Definition Audio)	-60 d8	3m ·····		1						-45
<b>v</b>	25	$\prod_{i=1}^{n}$			0s -80 d8 -90 d8 -100 d	3m 3m 1Bm				~~~~~			-80 dBm -90 dBm -100 dBm	-75 -90
٨	25	L	- <b>A</b>	1.	-110 c -120 c	iBm ,						~~_ <mark>_</mark> ~~~~	-110 dBm -120 dBm	-105 -120 -135
IF Di	splay				•	105.4	50	105.500	)	1	05.550	105.600		
Mod Filter AGC	e Off				€ CW E	ecoder	105.400	105.50	0	105.600	1	.05.700	x2 • 🕑	-150 • ×

Installer le logiciel Sdr console décrit dans le tutoriel 9.2.2, page 4.

Télécharger le fichier ExtIO\_RTL\_TCP\_2020-1.zip



Copier le fichier ExtIO\_RTL\_TCP.dll dans le répertoire d'installation de HDSDR



Puis Exécuter le programme HDSDR MUSCR

#### Sélectionner le fichier ExtIO\_RTL\_TCP.dll

Choose which External HW should be u	used by Hi	DSDR	-		×
✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	HDSDR		Rechercher	r dans : HDS	IDR 🔎
Organiser 🔻 Nouveau dossier					
<ul> <li>OneDrive</li> </ul>	*	Nom	^		Modifié le
🐺 Dropbox		String Red	Pitaya TRX.dll		21/02/2019
Ribliothèquer		S ExtIO_RTL	_TCP.dll		01/11/2020
Documents		SttIO_RTL	2832.dll		10/10/2020
🔛 Images	E				
🎝 Musique					
📑 Vidéos					
1 Vrdinateur					
🕌 Disque local (C:)					
💼 temp (E:)	Ψ.	•	III		+
Nom du fichier :	ExtIO_RTL_	_TCP.dll	✓ External IO I	HW DLL (Ext	IO_*.dll) ▼
			Ouvrir	<b>T</b>	annuler

Arrêter l'écoute en appuyant sur Stop[F2], puis renseigner la bonne adresse IP dans SDR Device [F8]. Une fois configuré appuyer sur Start[F2].

12:26:36 12:26:37 12:26:39						-				
12:26:40 12:26:41 12:26:42	Everto RTL TCP DLL v2020 1									
104400 -25 -30 -90 -25 -30 -90 -125 -100 -125 -150 Peak 5 9 +64 dB SOR-Device [F8] Soundcard [F5] Bandwidth [F6] Options [F7] Full Screen [F11] Start [F2] Minimize [F3]	Source IP-Rot           192 168.1 55:1234           Autom. ReConnect           Arborn ReConnect           VP           Persistent Connection           VI           Persistent Connection           VI           Persistent Connection           VI           Persistent Connection           VI           Sampling mode:           [//Q-sampling of tuner output           V           R2071/2-Tuner Band Center:           DC / Center: 0           V           / Decimation -> Output Rate ('):           [/1           V           Buffer Size:           64 kB           Verify ppm           401/111/2020 12:26:55	Tuner RF Gain AGC	Tuner IF Gain AGC       	105400 Project State St	105600 i:- \$ rtl_top - e(s): , RTL2830UHDIR 0: Generic RTL2 Micro R820T tum ot locked! 00000 Hz. e argument 'rtl mples in GRC an ed! 608 bytes for r ] [ bytes_in mpling 0 ct sampling mod ning 0 ection 0 90000 1 gefall The Bay	105800 105800 -a 192.168.1.55 R, SN: 00000001 1832U OEM ter 1_tcp=192.168.1. d control rtl_t ringbuf. flight(cur/max) ie	106000 1 55:1234' in ( cp parameter: = 256K /	106200 106200 D3moSDR (gr-osmosc s (frequency, gair OK ]	106400	106600 RF -7 dBFS 5000 5 dBFS •
Exit [F4]	CPU HDSDR: 0%			Spec	trum	Zoom	Speed			

	80   ExtIO_RTL	_TCP.dll@8bit   SRate: 2400000 > 12000	OS: 6.1.7601 SP 1   CPU	J: AMD A6-6420K AF	U with Radeon HD Graphics	RAM: 7366MB				
12:42:25 12:42:26 12:42:27			R. I							
12:42:29 12:42:30 12:42:31			1. (1) - (1)	2						
<u>12</u> :42:33 <u>12</u> :42:34				13			個國			
<u>12</u> :42:35 <u>12</u> :42:37 <u>12</u> :42:38								-1 <b>8</b>		
12:42:39 12:42:40 12:42:42										
<u>12</u> :42:43 <u>12</u> :42:44							<u> </u>			
7020	)	7030 7040	7050 70	060 T	7070 7080	7090	7100	<u>7110</u>	7120	7130
-25		Extlo_RTL_TCP.DEL v2020.1		<u> </u>	pi@raspberrypi: ~					_ D
-75	moundulour	Source IP:Port 192 168 1 55-1234	Tuner RF Gain HF AGC	Tuner IF Gain IF AGC	worker socket bye					^
-100		132.100.1.33.1234			Signal caught, exi	ting!				
-125		Autom PoConnort			comm recv bye					
		Autom. ReConnect			comm recv bye Signal caught, exi	ting!				
Peak +40	AM ECSS	Autom. ReConnect [ Persistent Connection [ A/D Sample Bate:			comm recv bye Signal caught, exi all threads dead listening	ting!				
Peak +20 +40	AM ECSS	Autom. ReConnect [ Persistent Connection [ A/D Sample Rate: 2.4 Msps			comm recv bye Signal caught, exi all threads dead listening Use the device arg to receive samples	ting! ument 'rtl_tcp=192 in GRC and contro	2.168.1.55:123 51 rt1_tcp par	34' in OsmoSDR rameters (freque	(gr-osmosdr) so ency, gain,	ource .).
Peak +20 +40	AM ECSS	Autom. ReConnect [ Persistent Connection [ A/D Sample Rate: 2.4 Msps Sampling mode:		- [ -    	comm recv bye Signal caught, exi all threads dead listening Use the device arg to receive samples ^CSignal caught, e bue!	ting! ument 'rtl_tcp=192 in GRC and contro xiting!	2.168.1.55:123 D1 rtl_tcp par	34' in OsmoSDR cameters (freque	(gr-osmosdr) so ency, gain,	ource .).
Peak +20 +20 7 3 5-units 5quelch	AM ECSS LO A Tune	Autom. ReConnect         [           Persistent Connection         [           A/D Sample Rate:         2           12 4 Maps         -           Sampling mode:         [           [m Q: aliases 0 - 14.4 - 28.8 MHz! (V3)         -		    	<pre>comm recv bye Signal caupht, exi all threads dead. listening Use the device arg to receive samples ^CSignal caught, e bye! pi@raspberrypi:- \$</pre>	ting! ument 'rtl_tcp=192 in GRC and contro xiting! rtl_tcp -a 192.10	2.168.1.55:123 51 rtl_tcp par 68.1.55 -D	34' in OsmoSDR rameters (freque	(gr-osmosdr) so ency, gain,	ource .).
Peak +20 5 3 5 	AM ECSS LO A Tune Volume Gain:+19.5d	Autom, ReConnect Persistent Connection //D Sample Rate: 2.4 Msps Sampling mode: [pin Q: aliases 0 - 14.4 - 28.8 MHz! (V3) R2017/2-Tuner Bandwidth Automatic			comm recv bye Signal caught, exi all threads dead Use the device arg to receive samples ^CSignal caught, e bye! Pignaspberrypi:- \$ Found 1 device(s): 0: Realtek, RTL	ting! ument 'rtl_tcp=19: in GRC and contro xiting! rtl_tcp -a 192.14 2838UHIDIR, SN: 00	2.168.1.55:123 51 rtl_tcp par 58.1.55 -D 5000001	34' in OsmoSDR cameters (freque	(gr-osmosdr) so ency, gain,	ource .).
Peak +20 +40 -5 -5 -5 -5 -5 -5 -0 -1 -5 -0 -1 -2 -2 -2 -2 -2 -2 -2 -2 -2 -2	AM ECSS LO A Tune Volume Gain:+19.5d	Autom, ReConnect Persistent Connection //D Sample Rate: 2.4 Maps Sampling mode: [pin 0::alases 0 - 14.4 - 28.8 MHzl (V3) R820T/2-Tuner Bandwidth Automatic R820T/2-Tuner Band Center:			<pre>comm recv bye Signal caught, exi all threads dead Use the device arg to receive samples ^CSignal caught, e bye: pigraspberrypi:- \$ Found 1 device(s): 0: Realtek, RTL Using device 0: Ge</pre>	ument 'rtl_tcp=19; in GRC and contro xiting! rtl_tcp -a 192.1( 28380HIDIR, SN: 0( neric RTL2832U OEN	2.168.1.55:123 ol rtl_tcp par 58.1.55 -D 0000001 4	34' in OsmoSDR cameters (freque	(gr-osmosdr) so ency, gain,	ource .).
Peak +20 +20 +20 +20 +40 +20 +40 -7 -7 -5 -5 -11 dB -50 -11 dB -50 -11 dB -50 -50 -50 -50 -50 -50 -50 -50	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect Persistent Connection A/D Sample Rate: 2.4 Maps Sampling mode: [pin Q::alasses 0 - 14.4 - 28.8 MHz! (V3) R820T/2-Tuner Bandwidth Automatic R820T/2-Tuner Band Center: [DC / Center: 0			<pre>comm recv bye Signal caught, exi all threads dead Use the device arg to receive samples ^CSignal caught, e bye! pigraspherrypir- \$ Found 1 device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam</pre>	<pre>ument 'rtl_tcp=19; in GRC and contro xiting! rtl_tcp -a 192.1( 2838UHIDIR, SN: 0( neric RTL2832U OEN R820T tuner pling mode, input</pre>	2.168.1.55:123 ol rtl_tcp par 58.1.55 -D 0000001 4 2	34' in OsmoSDR rameters (freque	(gr-osmosdr) so ancy, gain,	ource .).
Peak ++0 7 9 5 9 5 0 -11 dB 50 -11 dB 50 -11 dB 50 -11 dB 50 -11 dB 50 -11 dB 50 -11 dB	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect         Persistent Connection           A/D Sample Rate:         2.4 Maps           2.4 Maps         Sampling mode:           [pin 0: allases 0 - 14.4 - 28.8 MHz! (V3)         R820T/2-Tuner Bandwidth           Automatic         R820T/2-Tuner Band Center:           [DC / Center: 0         -           / Decimation -> Output Rate ("):         -			comm recv bye Signal caught, exi all threads dead. Use the device arg to receive samples ^CSignal caught, e bye! plgraspberrypi:- \$ Found 1 device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam Enabled direct sam	<pre>ting! ument 'rtl_tcp=19: in GRC and contro xiting! rtl_tcp -a 192.1( 2838UHIDIR, SN: 0( neric RTL2832U OEN R820T tuner pling mode, input pling mode, input</pre>	2.168.1.55:123 51 rt1_tcp par 58.1.55 -D 50000001 4 2 2/Q.	34' in OsmoSDR cameters (freque	(gr-osmosdr) so ancy, gain,	Durce .).
Peak +20 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect         [           Persistent Connection         [           A/D Sample Rate:         24 Maps           24 Maps         -           Sampling mode:         [           [pin Q: allases 0 - 14.4 - 28.8 MHz! (V3)         -           R2071/2-Tuner Bandwidth			<pre>comm recv bye Signal caught, exi all threads dead. Use the device arg to receive samples ^CSignal caught, e bye! pl@raspberrypit- \$ Found 1 device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam Enabled direct sam Tuned to 10000000 listening</pre>	<pre>ting! ument 'rtl_tcp=19: in GRC and contro xiting! rtl_tcp -a 192.14 2838UHIDIR, SN: 00 neric RTL2832U OEN R820T tuner pling mode, input Hz.</pre>	2.168.1.55:123 50 rt1_top par 58.1.55 -D 50000001 4 2 2/Q.	34' in OsmoSDR cameters (freque	(gr-osmosdr) so ency, gain,	ource .).
Peak ++0 5 5 5 5 5 5 5 5 5 5 5 5 5	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect         [           Persistent Connection         [           A/D Sample Rate:         24 Maps           24 Maps         [           Sampling mode:         [           [pin Q: aliases 0 - 14.4 - 28.8 MHz! (V3)         [           R202T/2-Tuner Bandwidth         [           Automatic         [           R202T/2-Tuner Band Center:         [           [DC / Center: 0         -           / Decimation -> Output Rate (*):         [           [/1         -           Buffer Size:         [           Fat Jen         -			<pre>comm recv bye Signal caught, exi all threads dead. Use the device arg to receive samples ^CSignal caught, e bye! pl@raspberrypl:~ S Found 1 device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam Enabled direct sam Tuned to 10000000 listening Use the device arg</pre>	<pre>ting! ument 'rtl_tcp=19; in GRC and contro xiting! rtl_tcp -a 192.14 2838UHIDIR, SN: 00 neric RTL2832U OED R820T tuner pling mode, input pling mode, input Hz. ument 'rtl_tcp=19; a control actors actors actors to control actors actors to control actors to cont</pre>	2.168.1.55:123 51 rt1_top par 58.1.55 -D 50000001 4 2 2/Q. 2.168.1.55:122 2 ot 1 or 200	34' in OsmoSDR rameters (freque 34' in OsmoSDR	(gr-osmosdr) so ency, gain, (gr-osmosdr) so	ource
Peak +20 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect         [           Persistent Connection         [           A/D Sample Rate:         24 Maps           24 Maps         [           Sampling mode:         [           [pin Q: aliases 0 - 14.4 - 28.8 MHz! (V3)         [           R2027/2-Tuner Bandwidth         [           Automatic         [           R2027/2-Tuner Band Center:         [           [DC / Zenter: 0         -           / Decimation -> Output Rate (*):         [           [/1         -           Buffer Size:         [           [64 kB         -	Image: Constraint of the second sec		<pre>comm recv bye Signal caught, exi all threads dead. Use the device arg to receive samples ^CSignal caught, e bye! pl@raspberrypl:~ S Found 1 device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam Enabled direct sam Tuned to 10000000 listening Use the device arg to receive samples client accepted!</pre>	ting! ument 'rtl_tcp=19: in GRC and contro xiting! rtl_tcp -a 192.14 2838UHIDIR, SN: 00 neric RTL2832U OED R820T tuner pling mode, input Hz. ument 'rtl_tcp=19: in GRC and contro	2.168.1.55:123 51 rt1_tcp par 58.1.55 -D 50000001 4 2 2/Q. 2.168.1.55:123 51 rt1_tcp par	34' in OsmoSDR cameters (freque 34' in OsmoSDR cameters (freque	(gr-osmosdr) so ency, gain, (gr-osmosdr) so ency, gain,	purce .).
Peak ++0 +20 ++0 5 -5 5 -11 dB 50 -1	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect         [           Persistent Connection         [           A/D Sample Rate:         24 Maps           24 Maps         [           Sampling mode:         [           [         pin Q: allases 0 - 14.4 - 28.8 MHz! (V3)           R2207/2-Tuner Bandwidth         [           Automatic         R2207/2-Tuner Band Center:           [         Dc / Center: 0           / Decimation -> Output Rate (*):         [           [         1           Buffer Size:         [           [         64 k.B           Prequency Correction:         [           [         [	Y     -       Y     -       Y     -       Y     -       Y     -       Y     -       Y     -       R820T/2 AGC V       E4000 Offset       RTL DIG AGC V		<pre>comm recv bye Signal caught, exi all threads dead Use the device arg to receive samples ^CSignal caught, e bye! plgraspberrypi:- \$ Found 1 device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam Tuned to 100000000 listening Use the device arg to receive samples client accepted! Allocate 3388608 b</pre>	<pre>ting! in GRC and contro xiting! rtl_top -a 192.14 2838UHIDIR, SN: 00 neric RTL2832U OEN R820T tuner pling mode, input H2. ument 'rtl_top=192 in GRC and contro ytes for ringbuf.</pre>	2.168.1.55:123 501 rtl_tcp par 58.1.55 -D 0000001 4 2 2/Q. 2.168.1.55:123 51 rtl_tcp par	34' in OsmoSDR cameters (freque 34' in OsmoSDR cameters (freque	(gr-osmosdr) so ancy, gain, (gr-osmosdr) so ency, gain,	Durce .).
Peak +20 +20 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	AM ECSS LO A Tune Volume Gain:+19.5d	Autom. ReConnect Persistent Connection A/D Sample Rate: 24 Maps Sampling mode: pin Q: aliases 0 - 14.4 - 28.8 MHz! (V3) R202T/2-Tuner Bandwidth Automatic R202T/2-Tuner Band Center: DC / Center: 0 / Decimation -> Output Rate (*): [/1 Duffer Size: 64 kB Frequency Correction: 0 pm	Image: state of the s		<pre>comm recv bye Signal caught, exi all threads dead. Use the device arg to receive samples ^CSignal caught, e bye! pl@raspberrypl:- \$ Found I device(s): 0: Realtek, RTL Using device 0: Ge Found Rafael Micro Enabled direct sam Tuned to 10000000 listening Use the device arg to receive samples client accepted! Allocate \$388608 b Westerial is RBW</pre>	ting! ument 'rtl_top=19; in GRC and contro xiting! rtl_top -a 192.1( 2838UHIDIR, SN: 0( neric RTL2832U OE) R820T tune, SN: 0( neric RTL2832U OE) R820T tune, input Pling mode, input H2. ument 'rtl_top=19; in GRC and contro ytes for ringbuf. 5.9 Hz 1 ~ ^	2.168.1.55:123 50 rt1_tcp par 58.1.55 -D 50000001 4 2 2/Q. 2.168.1.55:123 501 rt1_tcp par	34' in OsmoSDR cameters (freque 34' in OsmoSDR cameters (freque	(gr-osmosdr) so ency, gain, (gr-osmosdr) so ency, gain,	ource .). 

## 10.3.4 Sdruno

Installer le logiciel Sdruno décrit dans le tutoriel 9.2.5, page 12.

Télécharger le fichier ExtIO\_RTL\_TCP\_2020-1.zip

Copier le fichier ExtIO RTL TCP.dll dans le répertoire Documents



Exécuter le fichier SDRuno (Extio), installé dans le disque dur. (Faire une recherche lorsque l'on ne sait pas où le programme a été installé). Remarquer qu'il y a un manuel en pdf (SDRuno User manual) et c'est bien le seul manuel installé avec le programme parmi les 4 logiciels présentés ici.

#### ":+ SDRuno (EXTIO)

- Reset SDRuno Registry Settings
- ☆ SDRuno
- SDRuno User Manual
- "> Uninstall SDRuno

Vérifier la bonne prise en compte du fichier ExtIO RTL TCP.dll afin que le logiciel puisse accéder à la clé rtl-sdr.

🚓 Choose which	ExtIO should be used by Studio 1		×
Regarder dans :	Mes documents	← 🗈 💣 📰▼	
Ca	Nom	Modifié le	Туре 🖍
Emplacemente	SYNTHESE PROJET BALLON	26/05/2018 07:03	Dossier (
récents	퉬 temp	14/09/2017 17:48	Dossier (
	퉬 TmForever	28/04/2018 18:11	Dossier (
	퉬 upload sans compil	06/04/2018 19:56	Dossier (
Bureau	퉬 VirtualDJ	16/04/2020 21:15	Dossier (
-	퉲 xml	11/09/2019 19:47	Dossier (
	Joom Joon	30/08/2020 17:10	Dossier (
Bibliothèques	🎍 zoom_arrl	28/08/2020 11:54	Dossier (
	Downloads	30/09/2018 11:53	Raccour
	S ExtIO_RTL_TCP.dll	01/11/2020 12:19	Extensio
Outintere	ExtIO_RTL2832.dll	04/10/2020 17:10	Extensio ≡
Ordinateur	ExtIO_RTLSDR_u8.dll	11/10/2020 11:46	Extensio
	✓ [		F T
Réseau	Nom du fichier : ExtIO_RTL_TCP.dll	<b>-</b>	Ouvrir
	Types de fichiers : External IO HW driver (DLL)	▼ A	nnuler





#### F4GOH – KF4GOH Modifier l'adresse IP en veillant bien à utiliser la vôtre.

ExtIO_RTL_TCP.DLL v2020.1			×
Source IP:Port 192.168.1.55 1234		Tuner RF Gain AGC	Tuner IF Gain AGC
Autom. ReConnect	V		
Persistent Connection	$\overline{\mathbf{v}}$		
A/D Sample Rate:			
2.304 Msps (192.0 kHz)	-	: :	
Sampling mode:			
I/Q - sampling of tuner output	-		
R820T/2-Tuner Bandwidth			: :
Automatic	-		
R820T/2-Tuner Band Center:			
DC / Center: 0	-		
/ Decimation -> Output Rate (*):			
/1	-	11	
Buffer Size:			- 1 -
64 kB	-	R820T/2 AGC 🔽	IF AGC 🔽
Frequency Correction:		E4000 Offset 🗖	Tune USB
0 _ ppm		RTL DIG AGC 🔽	



A ce jour je n'ai pas réussi à utiliser rtl\_tcp avec SDRuno en réception HF (direct sampling mode)

# 10.4 Installation du serveur SPY Server

<u>Spyserver</u> fonctionne un peu de la même manière que rtl\_tcp, mais avec en plus la possibilité de partager sa station d'écoute. Celle-ci apparait sur la <u>carte du monde</u>. Il n'y a plus qu'à recopier l'adresse IP et le port dans son logiciel SDR préféré et ainsi faire de l'écoute.



Avec l'utilitaire Putty, taper ces commandes dans l'ordre :

# mkdir spyserver cd spyserver/ wget -0 spyserver.tgz http://airspy.com/?ddownload=4247 ls



Décompresser le fichier, puis éditer le fichier de configuration spyserver.config

tar xvzf spyserver.tgz

#### ls

nano spyserver.config



Configurer votre serveur en utilisant l'exemple ci-dessous :

# SPY Server Configuration File	# AirspyHF+	# Initial Center Frequency
# TCP Listener	# Auto (Scans for the first available	initial frequency = 7100000
	device)	a. <u>_</u>
bind_host = 192.168.1.55		# Minimum Tunable Frequency
bind_port = 5555-6666	device_type = RTL-SDR	# Comment if using the device default
# List Somer in Airony Directory	# Davias Cariel Number of 64bit Lloy	# #minimum fraguancy 0
# List Server in Airspy Directory	# Device Serial Number as 64bit Hex # For example: 0xDD52D95C904534AD	#minimum_frequency = 0
list in directory = 1	# A value of 0 will acquire the first	# Maximum Tunable Frequency
	available device.	# Comment if using the device default
# Owner Name	#	C C
# For example: John Doe L8ZEE	device_serial = 0	<pre>#maximum_frequency = 35000000</pre>
owner_name =f4goh		
# Ourper emeil	# Device Sample Rate	# Frequency Correction in PPB
# Owner email # For example: jobn@doe.com	# Possible values. # Airspy R0, R2 : 10000000 or 2500000	# #frequency_correction_pph = 0
owner email =f4goh@orange.fr	# Airspy Mini : 6000000 or 300000	#irequency_correction_ppb = 0
	# Airspy HF+ : 768000	# Initial Gain
# Antenna	# RTL-SDR : 500000 to 3200000	#
# For example: Random Wire/Magnetic	# Comment to use the device's default	#initial_gain = 5
Loop/Mini-Whip/Inverted V/etc.		
antenna_type =dipole	#device_sample_rate = 2500000	# RIL-SDR Sampling mode
# Antonna Location	# Force 8bit Compression Made	# Quadrature = 0, # Direct Sampling   Branch = 1
# For example: 48 858332 2 294560	# The 8bit Compression mode has proven	# Direct Sampling $\Omega$ Branch = 2
antenna location $=47.89.0.27$	sufficiently good for most streaming use	rtl sampling mode = 2
	cases.	
# General Description	# Use it to same some internet bandwidth.	# Converter Offset
	#	# Set to -120000000 to enable the
general_description = test rx	#force_8bit = 1	SpyVerter offset
# Licer cossions	# Maximum Bandwidth	$\#$ converter_offset = -12000000
	# limits the maximum IO bandwidth the	# Bias-Tee
maximum clients = 1	clients can set	# For AirspyOne only - Useful for LNA's
	# Recommended value for WFM is	and SpyVerter
# Maximum session duration	200000	<pre>#enable_bias_tee = 0</pre>
# In minutes. 0 for no limit	# Recommended value for narrow band	
War and include a second state of the second s	modes is 15000	# Buffer Size (in milliseconds)
#maximum_session_duration = 30	# #maximum bandwidth - 15000	buffor size ms - 50
# Allow clients to return and change of		$builer_size_ins = 50$
gain of the device	# FFT Frames Per Second	# Buffer Count
#	$fft_fps = 15$	
allow_control = 1	# FFT Bins	buffer_count = 10
	# Bins = 2 <sup>fft_bin_bits</sup>	
# Device Type	(1) 1 · · · · · · · · · · · · · · · · · ·	
# Possible Values:	$ITT_DIN_DITS = 16$	
# AirspyOne (RU, RZ, Mini)		

Dans l'exemple de configuration rtl\_sampling\_mode = 2 pour une écoute en HF. Pour une écoute en VHF/UHF il suffit d'ajouter le caractère # pour mettre la ligne en commentaire (#rtl\_sampling\_mode = 2).

Exécuter le serveur.

./spyserver

pi@raspberrypi:~/spyserver \$ ./spyserver
SPY Server v2.0.1700
Copyright (C) 2016-2018 Youssef Touil - https://airspy.com
Reading the configuration file: spyserver.config
Listening for connections on 192.168.1.55:5555
Found Rafael Micro R820T tuner
[R82XX] PLL not locked!
Enabled direct sampling mode, input 2
Accepted client 192.168.1.13:26511 running SDR# v1.0.0.1765 on Microsoft Windows
NT 6.1.7601 Service Pack 1
Device was sleeping. Wake up!
Found Rafael Micro R820T tuner
[R82XX] PLL not locked!
Enabled direct sampling mode, input 2
Acquired an RTL-SDR device

# 10.5 Test avec 2 logiciels clients

# 10.5.1 Sdrsharp

Exécuter SDRSharp.exe, puis configurer la source (Spy Server Network) ainsi que l'adresse IP.



Dans cette configuration l'écoute est sur le réseau local. Pour pouvoir accéder depuis Internet il faut configurer la BOX ADSL.

RPI partie 10-V1.0.docx

#### 10.5.2 Sdr console

#### Même principe que pour la partie 10.3.2, mais avec SPY Server



RPI partie 10-V1.0.docx

#### 10.6 Configuration de la box ADSL

La configuration est identique au tutoriel 6.8 : Accéder au web SDR depuis l'extérieur du QRA.

La différence est dans le numéro du port (5555).

Retour Réseau									
DHCP	NAT/PAT	DNS	UPnP	DynDNS	DMZ	NTP	IPv6		
spyserver         5555         555         TCP         raspberrypi-2           ex. : 1000         ex. : 1000-2000         ex. : 1000-2000         ex. : 1000-2000         ex. : 1000-2000								rrypi-2 🔻	Créer
Activer	Applicatio	n/Service	Port	interne	Port exter	ne	Protocole	Équipement	
$\checkmark$	spyserver		ŧ	5555	5555		TCP	raspberrypi-2	Ê

Sur la carte du monde, ma station apparait, l'icône « ready » est en vert, il est possible d'accéder à ma station en recopiant l'adresse IP ainsi que le port :



## 10.7 Conclusion

Le partage de réception SDR est très facile à réaliser avec un Raspberry pi. Cela pourra rendre de nombreux services dans diverses situations de tests. Je remercie Ladislav OK1UNL de m'avoir donné l'idée de ce tutoriel. Les utilisateurs de Linux pourront utiliser GQRX comme client pour le serveur.